Sistem automat de procesare de imagini pentru recunoașterea video a semnelor de circulație sau a culorilor de la semafor, folosind Raspberry PI și o cameră video atașată

Proiect - Sisteme Incorporate - 2023/2024

Autori:

Henţiu Alexian-Tudor, CTI-ro Anul III Kondora Norbert, CTI-ro Anul III Vasile Ioana, CTI-ro Anul III

=

Cuprins

Descrierea lucrării	
Hardware	4
Software	
Bibliografie	10

Descrierea lucrării

Echipamente utilizate:

- Raspberry Pi 4B cu specificaţiile:
 - Broadcom BCM2711, Quad core Cortex-A72 (ARM v8)
 64-bit SoC @ 1.8GHz
 - o 4GB LPDDR4-3200 SDRAM
 - 2.4 GHz and 5.0 GHz IEEE 802.11ac wireless, Bluetooth
 5.0, BLE
 - Gigabit Ethernet
 - 2 USB 3.0 and 2 USB 2.0 ports
 - 40-pin GPIO header, backward compatible
 - 2 micro-HDMI ports, supporting 4K displays
 - USB-C for power supply
- Raspberry Pi Camera 1.3 cu specificaţiile:
 - 5 MP OmniVision OV5647 sensor
 - o 1080p30, 720p60 and 640 × 480p60/90 video modes
 - Comunicare prin CSI (Camera Serial Interface)





Mod de lucru:


Am utilizat modelul *ssd-mobilenet-v2-fpnlite-320*, disponibil în Tensorflow 2 Model Zoo. Acesta a fost antrenat pentru 40000 de iterații cu un batch size de 16 imagini, pe un dataset realizat de noi. Am ales acest model datorită performanței cu care rulează pe Raspberry Pi, spre deosebire de alte modele care necesită mai multe resurse.

Dataset-ul cuprinde aproximativ 300 de imagini cu indicatoare rutiere de 3 tipuri: Cedează trecerea, Oprirea interzisă și Trecere de pietoni. Imaginile au fost preluate de pe Google Maps Street View și au fost etichetate manual, una câte una, utilizând programul open-source *Labellmg*.


Antrenarea finală a modelului a fost realizată folosind backend-ul Google Compute Engine cu GPU-ul T4, în Google Collab Pro și a durat aproximativ 4 ore. După antrenare, modelul a fost convertit la formatul *tensorflow-lite* și cuantizat, convertind weight-urile din numere în virgulă flotantă pe 32 de biți în numere întregi pe 8 biți. Această conversie a avut ca scop cresțerea performanței în schimbul unei reduceri minore (în acest caz) a acurateții de detecție.

Sistemul final rulează prin execuția unui script Python pe Raspberry Pi, care utilizează un API de nivel înalt pentru comunicarea cu camera video.


Hardware



Schemă conectori Raspberry Pl



Schema internă conector CSI



Diagramă bloc OV5647

Software


Modelul SSD MobileNet V2 FPNLite

Arhitectura **SSD MobileNet V2 FPNLite** reprezintă o combinație între arhitectura **MobileNet v2** pentru extragerea caracteristicilor și arhitectura **Single Shot Detector (SSD)** pentru detecția obiectelor, cu adăugarea unui modul **Feature Pyramid Network Lite (FPN Lite)**. Acest model a fost preantrenat pe setul de date COCO 2017 și este format dintr-o rețea de bază (MobileNetV2), o rețea de detecție (Single Shot Detector or SSD) și o rețea pentru extragerea de caracteristici (FPN-Lite).

Rețeaua de baza, **MobileNet**, este bazată pe o rețea neuronală convoluțională, proiectată pentru calcul eficient pe dispozitive mobile și integrate, care oferă caracteristici de nivel înalt pentru sarcini de clasificare sau detecție. Dacă se folosește un strat complet conectat (fully connected layer) și un strat softmax, modelul poate fi utilizat pentru sarcini de clasificare dar dacă acest strat complet conectat este înlocuit cu o rețea de detecție (ex.: SSD, Faster R-CNN) modelul poate fi utilitar pentru sarcini de detecție.

Rețeaua de detecție **SSD** (**Single Shot Detection**) este una dintre cele mai comune rețele de detecție folosite. Este un algoritm de detectare a obiectelor în timp real, capabil să detecteze mai multe obiecte într-o imagine cu o precizie ridicată. Algoritmul SSD se bazează pe o rețea neuronală convoluțională profundă (CNN) care primește o imagine ca intrare și produce o serie de cadre de delimitare și predicții de clasă pentru toate obiectele din imagine. Spre deosebire de alte algoritme de detectare a obiectelor, SSD realizează atât localizarea, cât și clasificarea într-o singură trecere a rețelei, de unde și denumirea de "single shot". SSD este proiectat să fie rapid și eficient, ceea ce îl face potrivit pentru aplicații în timp real, cum ar fi supravegherea video și conducerea autonomă.

FPN Lite este o versiune ușoară a arhitecturii Feature Pyramid Network (FPN), care este frecvent utilizată în sarcinile de detectare a obiectelor pentru a combina caracteristicile de înaltă rezoluție din straturile superficiale cu caracteristicile de rezoluție scăzută din straturile profunde pentru a îmbunătăți precizia detectării. În modelul ssd_mobilenet_v2_fpnlite, modulul FPN Lite este folosit pentru a combina ieșirea rețelei MobileNet v2 și straturile SSD, furnizând informații contextuale suplimentare pentru sarcina de detectare a obiectelor, cu scopul de a îmbunătăți precizia detectării obiectelor prin încorporarea informațiilor de la multiple scale.



Script Python pentru detecție în timp real utilizând camera conectată la Raspberry Pi:

```
# Import packages
import os
import argparse
import cv2
import numpy as np
import sys
import time
from threading import Thread
import importlib.util
# Define VideoStream class to handle streaming of video from webcam in separate processing
# Source - Adrian Rosebrock, PyImageSearch:
https://www.pyimagesearch.com/2015/12/28/increasing-raspberry-pi-fps-with-python-and-opencv/
class VideoStream:
    """Camera object that controls video streaming from the Picamera"""
    def __init__(self,resolution=(640,480),framerate=30):
        # Initialize the PiCamera and the camera image stream
        self.stream = cv2.VideoCapture(0)
        ret = self.stream.set(cv2.CAP PROP FOURCC, cv2.VideoWriter fourcc(*'MJPG'))
        ret = self.stream.set(3,resolution[0])
        ret = self.stream.set(4,resolution[1])
        # Read first frame from the stream
        (self.grabbed, self.frame) = self.stream.read()
       # Variable to control when the camera is stopped
        self.stopped = False
    def start(self):
       # Start the thread that reads frames from the video stream
        Thread(target=self.update,args=()).start()
        return self
    def update(self):
        # Keep looping indefinitely until the thread is stopped
        while True:
            # If the camera is stopped, stop the thread
            if self.stopped:
                # Close camera resources
                self.stream.release()
                return
            # Otherwise, grab the next frame from the stream
            (self.grabbed, self.frame) = self.stream.read()
    def read(self):
       # Return the most recent frame
        return self.frame
    def stop(self):
```

```
# Indicate that the camera and thread should be stopped
        self.stopped = True
# Define and parse input arguments
parser = argparse.ArgumentParser()
parser.add_argument('--modeldir', help='Folder the .tflite file is located in',
                    required=True)
parser.add_argument('--graph', help='Name of the .tflite file, if different than
detect.tflite',
                    default='detect.tflite')
parser.add argument('--labels', help='Name of the labelmap file, if different than
labelmap.txt',
                    default='labelmap.txt')
parser.add argument('--threshold', help='Minimum confidence threshold for displaying
detected objects',
                    default=0.5)
parser.add argument('--resolution', help='Desired webcam resolution in WxH. If the webcam
does not support the resolution entered, errors may occur.',
                    default='1280x720')
parser.add_argument('--edgetpu', help='Use Coral Edge TPU Accelerator to speed up
detection',
                    action='store true')
args = parser.parse args()
MODEL NAME = args.modeldir
GRAPH NAME = args.graph
LABELMAP NAME = args.labels
min conf threshold = float(args.threshold)
resW, resH = args.resolution.split('x')
imW, imH = int(resW), int(resH)
use_TPU = args.edgetpu
# Import TensorFlow Libraries
# If tflite_runtime is installed, import interpreter from tflite_runtime, else import from
regular tensorflow
# If using Coral Edge TPU, import the load delegate library
pkg = importlib.util.find spec('tflite runtime')
if pkg:
    from tflite_runtime.interpreter import Interpreter
        from tflite runtime.interpreter import load delegate
else:
    from tensorflow.lite.python.interpreter import Interpreter
    if use_TPU:
        from tensorflow.lite.python.interpreter import load_delegate
# If using Edge TPU, assign filename for Edge TPU model
if use TPU:
    # If user has specified the name of the .tflite file, use that name, otherwise use
default 'edgetpu.tflite'
    if (GRAPH NAME == 'detect.tflite'):
```

```
GRAPH NAME = 'edgetpu.tflite'
# Get path to current working directory
CWD PATH = os.getcwd()
# Path to .tflite file, which contains the model that is used for object detection
PATH TO CKPT = os.path.join(CWD PATH, MODEL NAME, GRAPH NAME)
# Path to label map file
PATH TO LABELS = os.path.join(CWD PATH, MODEL NAME, LABELMAP NAME)
# Load the label map
with open(PATH_TO_LABELS, 'r') as f:
    labels = [line.strip() for line in f.readlines()]
# Have to do a weird fix for label map if using the COCO "starter model" from
# https://www.tensorflow.org/lite/models/object detection/overview
# First Label is '???', which has to be removed.
if labels[0] == '???':
    del(labels[0])
# Load the Tensorflow Lite model.
# If using Edge TPU, use special load delegate argument
if use TPU:
    interpreter = Interpreter(model_path=PATH_TO_CKPT,
                              experimental_delegates=[load_delegate('libedgetpu.so.1.0')])
    print(PATH TO CKPT)
else:
    interpreter = Interpreter(model path=PATH TO CKPT)
interpreter.allocate tensors()
# Get model details
input_details = interpreter.get_input_details()
output_details = interpreter.get_output_details()
height = input details[0]['shape'][1]
width = input details[0]['shape'][2]
floating_model = (input_details[0]['dtype'] == np.float32)
input mean = 127.5
input std = 127.5
# Check output layer name to determine if this model was created with TF2 or TF1,
# because outputs are ordered differently for TF2 and TF1 models
outname = output_details[0]['name']
if ('StatefulPartitionedCall' in outname): # This is a TF2 model
    boxes idx, classes idx, scores idx = 1, 3, 0
else: # This is a TF1 model
    boxes_idx, classes_idx, scores_idx = 0, 1, 2
```

```
# Initialize frame rate calculation
frame_rate_calc = 1
freq = cv2.getTickFrequency()
# Initialize video stream
videostream = VideoStream(resolution=(imW,imH),framerate=30).start()
time.sleep(1)
#for frame1 in camera.capture continuous(rawCapture, format="bgr",use video port=True):
while True:
    # Start timer (for calculating frame rate)
    t1 = cv2.getTickCount()
    # Grab frame from video stream
    frame1 = videostream.read()
    # Acquire frame and resize to expected shape [1xHxWx3]
    frame = frame1.copy()
    frame_rgb = cv2.cvtColor(frame, cv2.COLOR_BGR2RGB)
    frame_resized = cv2.resize(frame_rgb, (width, height))
    input data = np.expand dims(frame resized, axis=0)
    # Normalize pixel values if using a floating model (i.e. if model is non-quantized)
    if floating_model:
        input_data = (np.float32(input_data) - input_mean) / input_std
    # Perform the actual detection by running the model with the image as input
    interpreter.set tensor(input details[0]['index'],input data)
    interpreter.invoke()
    # Retrieve detection results
    boxes = interpreter.get tensor(output details[boxes idx]['index'])[0] # Bounding box
coordinates of detected objects
    classes = interpreter.get_tensor(output_details[classes_idx]['index'])[0] # Class index
of detected objects
    scores = interpreter.get tensor(output details[scores idx]['index'])[0] # Confidence of
detected objects
    # Loop over all detections and draw detection box if confidence is above minimum
threshold
    for i in range(len(scores)):
        if ((scores[i] > min conf threshold) and (scores[i] <= 1.0)):</pre>
            # Get bounding box coordinates and draw box
            # Interpreter can return coordinates that are outside of image dimensions, need
to force them to be within image using max() and min()
            ymin = int(max(1,(boxes[i][0] * imH)))
            xmin = int(max(1,(boxes[i][1] * imW)))
            ymax = int(min(imH,(boxes[i][2] * imH)))
            xmax = int(min(imW,(boxes[i][3] * imW)))
```

```
cv2.rectangle(frame, (xmin,ymin), (xmax,ymax), (10, 255, 0), 2)
            # Draw Label
            object name = labels[int(classes[i])] # Look up object name from "labels" array
using class index
            label = '%s: %d%%' % (object_name, int(scores[i]*100)) # Example: 'person: 72%'
            labelSize, baseLine = cv2.getTextSize(label, cv2.FONT HERSHEY SIMPLEX, 0.7, 2) #
Get font size
            label ymin = max(ymin, labelSize[1] + 10) # Make sure not to draw Label too
close to top of window
            cv2.rectangle(frame, (xmin, label_ymin-labelSize[1]-10), (xmin+labelSize[0],
label ymin+baseLine-10), (255, 255, 255), cv2.FILLED) # Draw white box to put label text in
            cv2.putText(frame, label, (xmin, label_ymin-7), cv2.FONT_HERSHEY_SIMPLEX, 0.7,
(0, 0, 0), 2) # Draw label text
   # Draw framerate in corner of frame
   cv2.putText(frame, 'FPS:
{0:.2f}'.format(frame_rate_calc),(30,50),cv2.FONT_HERSHEY_SIMPLEX,1,(255,255,0),2,cv2.LINE_A
A)
   # All the results have been drawn on the frame, so it's time to display it.
   cv2.imshow('Object detector', frame)
   # Calculate framerate
   t2 = cv2.getTickCount()
   time1 = (t2-t1)/freq
   frame_rate_calc= 1/time1
   # Press 'q' to quit
   if cv2.waitKey(1) == ord('q'):
       break
# Clean up
cv2.destroyAllWindows()
videostream.stop()
```

Bibliografie

Tool etichetare imagini:

https://github.com/HumanSignal/labelImg

Tensorflow2 Detection Model Zoo:

https://github.com/tensorflow/models/blob/master/research/object_detection/g3doc/tf2_d etection_zoo.md

Notebook antrenare model:

https://colab.research.google.com/github/EdjeElectronics/TensorFlow-Lite-Object-Detection-on-Android-and-Raspberry-Pi/blob/master/Train_TFLite2_Object_Detction_Model.ipynb#scrollTo=GSJ2wgGCixy2

Deployment pe RaspberryPi:

https://github.com/EdjeElectronics/TensorFlow-Lite-Object-Detection-on-Android-and-Raspberry-Pi/blob/master/deploy_guides/Raspberry_Pi_Guide.md

Datasheet OV5647:

https://static.sparkfun.com/datasheets/Dev/RaspberryPi/OV5647.pdf

Documentație oficială cameră video:

https://www.raspberrypi.com/documentation/accessories/camera.html

Scheme Raspberry Pi:

https://easyeda.com/modules/RASPBERRY-PI-4-MODEL-B-SCHEMATIC_0b85e106e09b4eb982fa59dc1bbc4dde

Surse despre modelul ales:

MobileNetV2 SSD FPN | Edge Impulse Documentation
Understanding Single Shot Detector (SSD) | by Elven Kim | Medium
tensorflow - What is the architecture of ssd_mobilenet_v2_fpnlite_640x640? - Data
Science Stack Exchange